

**Recommendations on the transport of dangerous goods  
Manual of Tests and Criteria  
(Fifth revised edition)**

**Corrigendum**

*Note* : Corrigenda to this edition, as well as any new amendments to the Recommendations on the Transport of Dangerous Goods, will be made available on the United Nations Economic Commission for Europe website at the following address:  
<http://www.unece.org/trans/danger/danger.htm>

**1. Page 69, Table 13.1**

*For* 3 (b) (iii) *read* 3 (b) (iv)

**2. Page 114, Figure 13.5.3.1, caption**

*For* (O) Roller  
(P) Chamber  
(Q) Pendulum holder  
(R) Pendulum holder support

*read* (P) Roller  
(Q) Chamber  
(R) Pendulum holder  
(S) Pendulum holder support

**3. Page 209, Figure 20.1(b), before the entry of Box 11 of the flow chart**

*For* 2.1 (a) *read* 20.1 (a)

**4. Page 229, Figure 21.4.3.1**

Replace the section view with the one in Figure 11.4.1.1.

**5. Page 280, 26.4.3.3.1, fourth sentence**

*For* 55 m *read* 55 mm

**6. Page 298, Table 28.2**

*For*  $\leq 20^{\circ}\text{C}$  or less *read*  $\leq 20^{\circ}\text{C}$

**7. Page 411, 41.3.4.4**

*For* Figure 1 *read* Figure 41.3.5.1

**8. Page 414, Figure 41.1, heading**

*For* Figure 41.1 *read* Figure 41.3.5.1

**9. Page 414, Table 41.1, heading**

*For Table 41.1 read Table 41.3.5.1*

**10. Page 436, Appendix 5, 5. Test criteria and method of assessing the results**

*For  $V_{\text{test vessel}}$  = Area of venting of tank read  $V_{\text{test vessel}}$  = Volume of 10 litre test vessel*

**11. Page 436, Appendix 5, 5. Test criteria and method of assessing the results**

*For  $V_{\text{IBC}}$  = Area of venting of tank read  $V_{\text{IBC}}$  = Volume of IBC*

---